



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1		Drive Cap Assemblies		24	63206	Attachable Plug (EURO)	1
1a	200369	Drive Cap Assembly (Black)	1	25	63207	Attachable Plug (UK)	1
2		Upper Housing		26	63208	Attachable Plug (AU)	1
2a	201388	Upper Housing (Black)	1				
3		Lower Housing					
3a	201389	Lower Housing (Black)	1				
4	69136	Switch Button	1				
5	13618	Motor Assembly	1				
6	S20656	Blade Drive Assembly	1				
7	15766	Blade Drive Screw	2				
8	63897	Hinge Assembly	1				
9	64535	Lock Keeper	1				
10	27864	Blade Hinge Screw	2				
11	201337	Circuit Board	1				
12	65828	Screw	2				
13	60701	Insulator	1				
14	60074	Cord Set/Power Supply	1				
15	25542	Hanger Bail	1				
16	64606	Front Housing Screw	2				
17	60804	Rear Housing Screws	2				
18	64003	Blade Bracket	1				
19	64013	Tension Spring	1				
20	64027	Blade Guide	1				
21	64139	Blade Screw	2				
22	63373	Ferrite Suppressor	1				
23	101594	Data Label Type C	1				

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.