



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	74061	Lower Housing-Service	1
2	73098	Upper Housing-ENVY	1
2	73113	Upper Housing-ENVY Clip	1
3	79049	Screw	7
4	66303	Blade Bracket	1
5	66122	Lever Arm	1
6	201001	Lever Arm Bushing	1
7	200967	Lever Arm Screw	1
8	66319	Blade Screw	2
9	75296	Blade Guard	1
10	73091	Motor/Sled Assembly	1
11	73061	Torsion Spring	1
12	73032	Yoke-Service	1
13	73102	Power Supply (not pictured)	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.