andis

MODEL DBLC ANIMAL CLIPPER 120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	79048	Housing Screw	5
2	200714	Lower Housing	1
3	79029	Motor Screw	2
4	79036	Motor Assembly	1
5	200756	Upper Housing Assembly	1
6	27864	Hinge Screw	2
7	63897	Hinge Assembly	1
8	64535	Lock Keeper	1
9	79026	Battery Pack	1
10	200717	Middle Housing	1
11	79047	Circuit Board Screw	3
12	79014	Circuit Board	1
13	79003	Switch Actuator	1
14	20658	Blade Drive Assembly	1
15	15766	Blade Drive Screw	2
16	200712	Drive Cap	1
17	201898	Charge Stand	1
18	79066	Charging Adaptor	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.